

## SWITCH PUSH-ON BUTTON



Push-on button type, made of plastic material, attached to a plastic base with 4mm socket terminals (spin-free).

Installed completely with base and terminal for easy connection of the circuit.